

Alarms	Analog Parameters
Data Connection Lost	Battery Voltage
Generator Running	Engine Hours ¹
Generator Excessive Running ¹	
Fail to Exercise ¹	
Battery Voltage High ²	
Battery Voltage Low ²	
Common Alarm ³	
Not In Auto ³	
On Generator Power ⁴	
Controls	
Remote Start/Stop (if activated by customer)	

All Alarms & Analog Parameters noted above are only available if so configured at Generator and ATS control panel.

It is recommended that a technician with communications experience be utilized to install and calibrate any optional OMN accessories.

¹ Generator Excessive Running, Fail to Exercise, and Engine Hours are available when configured through OmniView™. It is suggested that this is done at time of monitoring setup.

² Battery Voltage High & Low Alarms based upon Battery Voltage Threshold settings set up in OmniView™.

³ Noted Alarms require programming using Deep Sea Software and communication cable. Customer is responsible for having proper software and connection cables at time of install. The above Deep Sea Alarms are the standard Alarms selected by OMNIMETRIX. Please note that other Alarms can be configured using the Deep Sea Software. See Deep Sea 720 Control Panel instructions for further information.

⁴ On Generator Power Alarm requires optional Current Relay Kit installed on output side of Generator Circuit Breaker. Current Relay Kit to ship loose for Customer installation. Customer to provide materials and labor to install wiring between OMN Monitor and Current Relay Kit. See OMN Current Relay Kit Spec Sheet & Install Guide for more details. Please note that Current Relay Kit can be installed in other locations other than load side of Generator.