

Alarms	Analog Parameters
Data Connection Lost	Battery Voltage
Generator Running	Engine Hours <sup>1</sup>
Generator Excessive Running <sup>1</sup>	
Fail to Exercise <sup>1</sup>	
Battery Voltage High <sup>2</sup>	
Battery Voltage Low <sup>2</sup>	
Common Alarm <sup>3</sup>	
On Generator Power <sup>4</sup>	
Controls	
Control Relay Output 1: Remote Start/Stop (if wired & activated by customer)	

All Alarms & Analog Parameters noted above are only available if so configured at Generator and ATS control panel.

It is recommended that a technician with communications experience be utilized to install and calibrate any optional OMN accessories.

<sup>1</sup> Generator Excessive Running, Fail to Exercise, and Engine Hours are available when configured through OmniView. It is suggested to do this at time of monitoring setup.

<sup>2</sup> Battery Voltage High & Low Alarms based upon Battery Voltage Threshold settings set up in OmniView.

<sup>3</sup> Common Alarm requires optional Kohler Run/Common Alarm Kit. Kohler Run/Common Alarm Kit to be provided and installed by Customer. Customer to provide materials and labor to install wiring between OMN Monitor and Run/Common Alarm Kit. Please note that to utilize the Kohler Run/Common Alarm Kit, Customer may need Kohler SiteTech software at time of install.

<sup>4</sup> On Generator Power Alarm requires optional Current Relay Kit installed on output side of Generator Circuit Breaker. Current Relay Kit to ship loose for Customer installation. Customer to provide materials and labor to install wiring between OMN Monitor and Current Relay Kit. See OMN Current Relay Kit Spec Sheet & Install Guide for more details. Please note that Current Relay Kit can be installed in other locations other than load side of Generator.